




MIDI BOX 4

QUICK START GUIDE

MIDI THRU:
CONNECT TO NEXT
MIDI DEVICE INPUT

9V DC:
CENTER NEGATIVE
20mA MINIMUM

MIDI INPUT:
CONNECT TO OUTPUT
OF MIDI CONTROLLER



**CONTROL PORTS:
USE SWITCHES TO CONFIGURE EACH PORT**


TIP ACTIVE: SENDS MIDI DATA TO TIP OF PORT


RING ACTIVE: SENDS MIDI DATA TO RING OF PORT

TIP AND RING ACTIVE: SENDS MIDI TO BOTH TIP AND RING AT THE SAME TIME

TRS MIDI: SENDS MIDI DATA TO TIP OF PORT WITH RING SET TO 5V. SUPPORTS MIDI TRS SPECIFICATION

STATUS LED:

 POWER ON

 MIDI ACTIVITY